




selectronic

SP PRO Series 2i Fronius Symo (Advanced) Installation Overview

Must be read in conjunction with Fronius Symo and SP PRO installation notes.
Symo Advanced requires ACC Version 5.03 or higher.



Install Fronius according to the Fronius installation instructions.







Do Not offset plug.
White = '-'
Red = 'RS485 D-'
Black = 'RS485 D+'




Switch in
'Master' position.



Switch to RHB
'B' position.



Fall Back Testing
- Unplug
- Wait 10 seconds, check:



Fail Safe Testing
- Unplug
- Check:



Please ensure to run the SP LINK site configuration Wizard.
View installation guide:
HelpDoc. IN0049
www.selectronic.com.au/support

