

# Enphase IQ System Component List

## Enphase Microinverters and Monitoring



### IQ7-60-2-INT

Enphase **IQ 7 Micro™**, 240 VA nominal power, MC4 DC connectors, female AC connector. Compatible with 60-cell PV modules.



### IQ7PLUS-72-2-INT

Enphase **IQ 7+ Micro™** 290 VA nominal power, MC4 DC connectors, female AC connector. Compatible with 60- and 72-cell PV modules.



### IQ7X-96-2-INT

Enphase **IQ 7X Micro™**, 310 VA nominal power, MC4 DC connectors, female AC connector. Compatible with 96-cell PV modules.



### ENV-S-230-WM

Enphase **Envoy-S Metered™ +DRM**, multiphase communications gateway that controls Enphase Microinverters and measures production and consumption via CTs. Two 100A CTs included.



### Q-RELAY-1P-INT

Enphase **Q Relay™** controller for voltage/frequency compliance for single phase systems.



### Q-RELAY-3P-INT

Enphase **Q Relay™** controller with internal phase coupler for voltage/frequency compliance for two and three phase systems.



### CT-100-SPLIT

Enphase CT, split-core current transformer, for monitoring energy consumption and production.



### CT-200-SPLIT

Enphase CT, split-core current transformer, for monitoring energy consumption and production.



### CELLMODEM-02

Enphase **Mobile Connect™** cellular modem with 5-year data plan. Compatible with systems with up to 60 Micros.



### EPLC-04

Enphase **Power Line Carrier** Quantity 2.

## Enphase AC Battery and Accessories



### IQ7-B1200-LN-I-INT01-RV0

Enphase **AC Battery™** with integrated S270 Micro and Enphase-developed BMU, 260VA/1.2 kWh, 230 VAC indoor IP20 rated. Compatible with grid-tied PV systems using the Enphase Envoy.



### BWM-450MM-A / WM-600MM-A

Enphase **Battery Wall Mount Bracket™**  
Available in 450 mm and 600 mm.

## Enphase Cables and Accessories



### Q-25-10-240

Enphase **Q Cable™** Single phase for 1.05m portrait module pitch. Connector pitch is 1.3m.



### Q-25-17-240

Enphase **Q Cable™** Single phase for 1.7m landscape module pitch. Connector pitch is 2.0m.



### Q-25-10-3P-200

Enphase **Q Cable™** Three phase for 1.05m portrait module pitch. Connector pitch is 1.3m.



### Q-25-17-3P-160

Enphase **Q Cable™** Three phase for 1.7m landscape pitch. Connector pitch is 2.0m.



### Q-25-20-200

Enphase **Q Cable™** Single phase for 72-cell 2.0m landscape module pitch. Connector pitch is 2.3m.



### Q-25-20-3P-160

Enphase **Q Cable™** Three phase for 72-cell 2.0m landscape module pitch. Connector pitch is 2.3m.



### Q-TERM-R-10

Enphase **Q Cable™ Terminator**  
Cap for Q Cable ends.



### Q-TERM-3P-10

Enphase **Q Cable™ Terminator**  
Cap for 3-P ends.



### Q-DISC-10

Enphase **Q Cable Disconnect** tool for Q Cable connectors, MC and Amphenol DC connectors, and AC module mount.



### Q-SEAL-10

Enphase **Q Sealing Caps**, female sealing cap for unused Q Cable connectors.



### Q-25-RAW-300

RAW Enphase **Q Cable™** 2.5mm sq. unterminated weather resistant cables for single phase systems suitable for Field-Wireable Connectors. No connectors included.



### ET-CLIP-100

Enphase **Q Cable™ Rail Mount Cable Management Clip**. Pack of 100.



### Q-DCC-2

Enphase **IQ Replacement Adaptor** for MC4 DC connector.



### Q-CONN-R-10M

Enphase **Male Field-Wireable Connector**. Requires MC4 crimp tool for connections to Q Cable or RAW Q Cable.



### Q-CONN-R-10F

Enphase **Female Field-Wireable Connector**. Requires MC4 crimp tool for connections to Q Cable or RAW Q Cable.



### LCF-250-PC

**Line Filter** for commercial applications. Separates power line communication domains.